

# EVER FLOAT™

## SLIDING FLOAT SINKER



The biggest challenge with standard bubbles is that they are designed to break. Every time you push the stop in, you are putting a wedge into the bubble that eventually causes the bubble to crack and start to leak, which means you can't keep water out or in. So you grab another one out of the bag and start the process again. You also have to untie your line to take them off and on, and they have to be put on in the right direction. And it is not always easy to submerge these in water, especially on steep banks or from a boat. Standard clear floats/bubbles cost about \$5.99 to \$6.99 for a dozen quality floats.

The Ever Float bubble costs \$4.00 or \$10.00 for a 3 pack. It is guaranteed for 2 years from date of purchase.



The Ever Float is a patent pending sliding float or bubble. When filled with water it weighs approximately .75 ounces. But this is no ordinary bubble float.



Put your lucky fishing penny or pocket knife into the groove located at either end of the float. Give a twist to remove the insert.



Place your fishing line in the slot, making sure the bubble is above your swivel and leader. Unlike other floats, there is no special orientation needed as the Ever Float is bi-directional.



Snap the insert back in place and your bubble is secure. Reverse the process to remove the float from your line.



The line slides freely in the slot. If it does not, make sure the line is not being pinched by the insert.



Place your penny in the slot that circles the body of the float. Twist the penny to remove the cover.



Water, weights, rocks, coins or whatever you like can be placed in the hollow area. This is handy if you can't readily submerge the bubble to fill with water.



Snap the cover back into place. Reverse the process to remove the weight.